

How to Setup GPSTab

With an IOSix ELD

BEFORE YOU BEGIN

First you need to create an admin account and then give the access to the driver by creating a separate account for the driver's ELD application.


Contents

- 3 Set up your Admin Account
- 9 Add ELDs to GPSTab
- 13 Add Vehicles to GPSTab
- **18** Add Drivers to GPSTab
- 24 Install your ELD



Set up your Admin Account

Step 1: Click Either of These Buttons to Begin




Step 2: Enter Your Name and Email Address


When first establishing a GPSTab account you will start with the **Admin account** (which will need to be a different email from the driver account.)

Use your **Admin** email address for this part.


You'll add a Driver email address later.



Step 3: Enter Your Company Info



Step 4: Create A Password And Register






Email has been sent

Confirmation email has been sent to youremail@email.com Please check for an email from GPSTab and click on the included link to activate your account.

Step 5: Confirm Your Email Address






Add ELDs to GPSTab

Step 6: Click ELD to show options, then click ELDs and after that ADD ELD


Clicking ELD expands the other options




Step 7: Enter The Serial Number From The ELD

The IOSix serial number and firmware will be printed on a sticker inside the box.






Step 8: You Should Now See Your ELD Listed






Add Vehicles to GPSTab

Step 9: Click ELD, then Vehicles and ADD Vehicle




Step 10: Add Your Vehicle Info

Vehicle ID is your Truck Number




Step 11: Finish Adding Your Vehicle Info

Your ELD is now available to select from the "ELD No." drop-down menu.



Step 12: You Should Now See Your Vehicle Listed


Your ELD is now assigned to your vehicle





Add Drivers to GPSTab


Step 13: Click ELD, then click Drivers and ADD driver



Step 14: Add Your Driver Info


Driver email must be unique.

You can also generate a password for the driver's ELD application.



Step 15: Keep Adding Your Driver Info

Your Vehicle is now available to select from the Vehicle ID drop-down menu.




Step 16: Finish Adding Your Driver Info

This is where you enable ELD or E-log modes for your driver. Also you can activate PC or YM from here.


Please Note!

ELD Mode will be enabled for your Driver by default.



Step 17: You Should Now See Your Driver Listed

Your vehicle is now assigned to your Driver.






Install your ELD

Step 18: Locate Your Vehicle's Diagnostic Port

ENGINE OFF

To meet the requirements of the ELD rule, the GPSTab application must be launched and the ELD device must be connected prior to starting the engine.



Step 19: Connect The Cable To The Port + The ELD


ENGINE OFF

You can watch an IOSix installation video here:

https://www.youtube.com/watch?v=-TZ3RQdssgE&list=PLiQzvQxt4f5dhd-P0P3XyzaybiZZTGeaJ&index=1









IOSix ELD connects to 9-pin connector

Step 20: Install The GPSTab App On Your Smartphone




Step 21: Sign In To The GPSTab App On Your Phone



Step 22: Select Your Vehicle



Step 23: You Should See This Screen





For more information please contact

Sales Team

Phone: (888) 228-4460/ext 1

Email: sales@gpstab.com

Support Team

Phone: (888) 228-4460/ext 2

Email: support@help24.us

Additional videos are available at the GPSTab Youtube channel at

https://www.youtube.com/channel/UC_Scq-p5daVZ3TorAJ5kmVw.

