

# GPSTab DOT REFERENCE CARD

### **GPSTAB ELD**

The GPSTab ELD device plugs into the diagnostic port in a vehicle and is integrally synchronized with the engine. The ELD automatically records driving time and connects the GPSTab App on a mobile device via Bluetooth®.



UTECH product GPSTab ELD is approved and officially registered with the FMCSA.

All versions of GPSTab ELD can be found by visiting the government site: www.csa.fmcsa.dot.gov/ELD/List Enter keywords "GPSTab ELD" or "UTECH"

### DEVICE MALFUNCTION CLEARANCE GUIDE



BLUE FIRE		
MALFUNCTION	WHAT TO DO	
SOLID RED	Do NOT unplug the device; call customer support	
BLINKING BLUE	Turn the engine off and reconnect the plug	
BLINKING GREEN	Turn the engine on and restart the tablet	



BLUE LINK (WIRELESS LINK)	
MALFUNCTION	WHAT TO DO
NO LIGHT	Turn the engine off and check the cable connection
BLINKING BLUE	Turn the engine off and restart the tablet; call customer support



IOSiX	
MALFUNCTION	WHAT TO DO
NO LIGHT	Turn the engine off and reconnect the plug
TABLET SHOWS "SCANNING"	Call customer support

### IF YOUR TABLET SCREEN DOES NOT LOCK WHILE DRIVING



Failing to stop the vehicle and assure proper functioning of the ELD device and application will constitute as a DOT violation.

## FOR OFFICER LOG INSPECTIONS

Tap the "Menu" icon and Select "Inspection Module"



Tap "Begin Inspection" to let an officer view your logs directly from your device



Tap "Send Logs" to email a copy of your logs to an officer



Tap "Send Output File" to submit your ELD output file to the DOT via web services



# A

### ATTENTION!

For legal and safety purposes, please refrain from calling your office, customer support line, or safety personnel while driving.



To meet the requirements of the ELD rule, the GPSTab application must be launched and the ELD device must be connected prior to starting the engine. Drivers must log into the application, choose the vehicle, ensure the proper connection of the ELD device and start the engine. These steps are necessary to ensure that devices can recognize the engine start. Failure to follow these steps would result in violations of the ELD rule.

### **GETTING STARTED**



STEP 1: Hold the power button, generally found on the side of a mobile device, to turn on your tablet/smartphone.



**STEP 2:** Verify that your device has good **cellular data connection** by checking the cellular signal indicator at the top right corner of the home screen.



**STEP 3:** Assure that the device is fully charged by checking **the battery level** in the upper right corner of the home screen. We recommend keeping it connected to the charger at all times.



STEP 4: Locate and select the GPSTab ELD application icon from your home screen.



**STEP 5:** Enter **Username and Password** once prompted to the "Sign In" screen. Reset your password if needed.



STEP 6: Select your truck from the vehicle list once logged in. Press "Confirm" when prompted to the "Confirm Vehicle" screen. You have now accessed your logs record.



STEP 7: Your cellular device will connect to the ELD automatically. The status will be shown at the top of the main screen. Once connected to the ELD successfully - please start the engine so the device can recognize the power up event.

### AT THE END OF THE SHIFT



STEP 1: Switch your duty status to "Sleeper" or "Off Duty" mode in the "Logs" screen.



STEP 2: Log out of the app by tapping the "Menu" icon and selecting "Log Out" option.



STEP 3: Always restart your device prior to the start of a new shift.



STEP 4: Complete your required 10-hour break following each shift in order to meet regulatory requirements.



**NOTE:** The system will not count time **shorter than 10 hours** as a full break (ex: 9 hours, 59 minutes and 59 seconds, constitutes as a violation).

For any questions, please contact our Support Team at 888.228.4460 ext. 2 or send an email to support@help24.us